

INSTALLATION INSTRUCTIONS: 2015+ F-150 CAB GUARD



CAUTION:

This equipment is designed to be professionally installed by an approved up-fitter. Always wear ear and eye protection and exercise caution when installing Westcan products.





PREPARATION:


- 1. Ensure all parts are present and accounted for before installation. **Begin the installation of your cabguard before your rail caps**. Plan the location of your installation ahead of time and make sure your installation location does not impede any other components you are installing or damage the safety and functionality of your vehicle.
- 2. Exercise extreme diligence when drilling holes into a motor vehicle. Increasing complexity and model year changes can alter the location of fuel, hydraulic and electrical lines. Please visually inspect all locations prior to drilling.
- 3. Re-Torque the 3/8" x 1-3/4" Stainless Steeel Countersink Bolt every 3 month.


BOX CAP PREPARATION:


Some truck box lengths require the plastic truck box caps to be cut to expose the stake pocket cutout. Use the provided template as a guide for cutting the box cap (see last page). Exercise caution when cutting caps to avoid injury.















IF REQUIRED, INSTALL YOU RAILCAPS PRIOR TO PROCEEDING WITH STEP 4 OR GO TO STEP 13 FOR INSTALLATIONS WITHOUT RAILCAPS.














11. CENTER CAB GUARD ON TRUCK BOX.













17. CENTER CAB GUARD ON TRUCK BOX AND INSTALL A SECONDARY HOLD DOWN KIT.



IF YOUR INSTALLING A LED CABGUARD
PLEASE REFER TO THE WIREING PINOUT
BELOW.

- Red = Left Turn Signal
- Yellow = Right Turn Signal
- Black = Tail / Marker Lights
- Blue = Back Up Lights
- White = Chassis Ground

PRINT OUT AT A 1:1 SCALE AND CUT OUT. FOLD ALONG THE DOTTED LINE.



WESTCAN MANUFACTURING LTD.

DESCRIPTION:F-150 Front Stake Pocket Cutout Template.

ANG. FRAC. XX XXX ± 0.5° 1/32" ±0.01" ±0.005" DATE: 14/05/18 DRAWN BY: DTocher MATERIAL: PART NR: Sheet1 OF1

UNLESS OTHERWISE SPECIFIED, ROY:
DIMENSIONS ARE IN INCHES
TOLERANCE
DRAW

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF WESTCAN MANUFACTURING LITD. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF WESTCAN MANUFACTURING LITD IS PROHIBITED.

PROPRIETARY AND CONFIDENTIAL