

OVER CANOPY RACK BOX CAPS

PARTS LIST

- **DRIVERS FRONT BOX CAP**
- **DRIVERS REAR BOX CAP**
- **PASSENGER FRONT BOX CAP**
- **PASSENGER REAR BOX CAP**
- **INSTALLATION HARDWARE**

STEP 1:

ASSEMBLE THE OVER CANOPY RACK AS OUTLINED IN THE ASSEMBLY INSTRUCTIONS PROVIDED WITH THE OVER CANOPY RACK. NOTE THE SPECIFIC FRONT AND REAR CROSS BAR SPACING AND HEIGHT FOR YOUR APPLICATION.

STEP 2:

IF DESIRED, INSTALL CANOPY SEAL TAPE ON THE BOTTOM OF THE CAP TO HELP KEEP RAIN OR WATER OUT OF THE CUSTOMER'S TRUCK BOX (NOT SUPPLIED). REMEMBER TO ALSO INSTALL EXTRA CANOPY SEAL ALONG THE FRONT OF THE CANOPY BECAUSE IT WILL SIT OFF OF THE BOX OF THE TRUCK ONCE THE CAP IS BETWEEN THE CANOPY AND THE TRUCK BOX.

STEP 3:

SET ALL THE CAPS IN PLACE ON THE TRUCK BODY AND FASTEN THE OVER CANOPY RACK TO THE BOX CAPS. ENSURE THE PLACEMENT OF THE BOX CAPS DO NOT INTERFERE WITH THE OPERATION OF THE VEHICLE. MARK THE CENTER POINT OF EACH COUNTERSINK HOLE AND DRILL A 3/8" HOLE. FASTEN THE BOX CAPS TO THE TRUCK BOX USING THE 3/8" X 1-1/2" STAINLESS STEEL COUNTER SINK BOLTS THROUGH THE COUNTER SUNK HOLES WITH THE NYLOCK BOLTS AND WASHERS.

STEP 4:

TIGHTEN THE BOLTS GOING THROUGH THE BOX WASHER INTO THE STAKE POCKET AND THEN TIGHTEN THE TOP BOLTS TIGHT.

STEP 5:

MEASURE ACROSS THE FRONT AND THE REAR OF THE BOX CAPS TO THE OUTSIDE POINTS. WRITING DOWN THESE MEASUREMENTS WILL ASSIST YOU IN ASSEMBLING THE RACK TO THE APPROPRIATE POSITIONS.

TECH SUPPORT 1-877-795-7733